

## Topic: How to install the 9364 bulb onto the Midmark light.

**Step 1.** Turn light head off and allow bulb (1) to cool for at least 5 minutes.

**Step 2.** Rotate the two release levers (2) up ¼ turn (located on each side of the light head) and remove plastic shield (3).

**Step 3.** Remove bulb by pulling bulb straight out of lamp socket (5) and discard.

**Step 4.** Using protective plastic the bulb is packaged in, align contact pins with socket holes and press bulb in firmly. When bulb is firmly seated there will be approximately a 1/8" gap between the base of bulb and bulb socket.

**Step 5.** Position plastic shield onto light head. Secure in place by rotating the two release levers down ¼ turn.

